

## Freestanding Bathtub and Overflow Waste Kit

This procedure will assist you with installing the Sinkology Freestanding Bathtub.

### GETTING STARTED

- Professional Install Recommended

**You will need:** To complete this procedure, you will need a Tape Measure, Plumbers Putty, 100% Neutral-Cure Silicone Sealant, a Phillips Screwdriver, a Carpenters Pencil, a Utility Knife, a Pipe Cutter, a Level, and Safety Glasses and Gloves.

Depending on the plumbing in the installation area, you may also need a variety of tools, such as a Drill, a Hole Saw, a Jigsaw, Painters Tape, or Teflon Tape.

Freestanding Bathtub installation instructions are available on the BILT® App. Download the BILT App today and search "Sinkology" to find install instructions specifically for your product and installation type or scan the QR Code for easy access.

SCAN FOR BILT 3D INSTRUCTIONS



POWERED BY BILT INTELLIGENT INSTALLATION

### INSTRUCTIONS

1. Run the drain pipes through the floor and attach to the plumbing. Rough-in the water supply and drain lines to the fittings to ensure proper fit before assembly, and make adjustments if needed. Install the Faucet. Note: We recommend using the Sinksense rough-in kit model #SDT901-PCV.
2. Set the Bathtub on its side.
3. Position the Bottom Drain Pipe and hold it in place for the next step.
4. Attach the Drain Gasket and the Drain Mechanism to the Bottom Drain Pipe.
5. Place the Bathtub upright in its final location.
6. Attach the Pipe Extension to the Drain Pipe. Connect the Pipe Bezel to the Pipe Extension.
7. Position the Overflow Pipe and hold it in place for the next step.
8. Attach the Overflow Cap to the Overflow Pipe using the Overflow Cap Screw.
9. Remove the Pipe Nut and Compression Washer from the bottom of the Tee Connector. Attach the Pipe Nut and Compression Washer to the Pipe Extension.
10. Remove the Pipe Nut and Compression Washer from the Tee Connector and slide them onto the Overflow Pipe. Attach the Tee Connector to the Overflow Pipe and secure the Tee with the Pipe Nut.
11. Remove the Pipe Nut and Compression Washer from the Tee Connector. Place the Pipe Nut and Compression Washer to the Bottom Drain Pipe. Secure the Tee Connector to the Bottom Drain Pipe and tighten the Pipe Nut. Secure the Tee Connector to the Pipe Extension with the Pipe Nut.
12. Turn on the water, check for leaks, and repair if needed.
13. If you wish to seal the Bathtub to the floor, we recommend using 100% Neutral-Cure Silicone Sealant. Note: Allow the Sealant time to cure properly before using the Bathtub.

**Congratulations**, this completes the installation of the Sinkology Drop-In Sink.

### LIFETIME WARRANTY

All Sinkology products are fully backed with a lifetime warranty - the Sinkology Everyday Promise.



### SHOW US YOUR SINK

Join our online community of thousands of happy customers who are showcasing our products in their homes to automatically be entered into our **\$1,000 gift card giveaway**.

Visit [Sinkology.com/ShowUsYourSink](https://Sinkology.com/ShowUsYourSink) for more details.