

## Bath Sink Drain

This procedure will assist you with installing Sinkology Bath Drains.

### GETTING STARTED

**You will need:** Plumber's Putty

Drain installation instructions are available on the BILT® App. Download the BILT App today and search "Sinkology" to find install instructions specifically for your product and installation type or scan the QR Code for easy access.



### INSTRUCTIONS

1. Important: Sinkology offers two styles of Bath Drains. Bath Drains that have a no-overflow design and should only be installed into bathroom sinks without overflow holes, whereas Bath Drains that have an overflow design should be installed into bathroom sinks with overflow holes.
2. Remove the Lock Nut, White Plastic Washer, and Rubber Washer from the Drain Stem.
3. Apply Plumber's Putty on the underside of the Drain Lip.
4. Slide the Drain into the drain hole.
5. Wipe off any excess Plumber's Putty. Note: The Drain and the metal of the Sink will be touching with a thin layer of Plumbers Putty creating a water tight seal around the Drain.
6. Place the Large Steel Washer over the Drain Pipe.
7. Slide the Rubber Washer onto the Drain Stem.
8. Slide on the White Washer, then tighten the Lock Nut onto the threads until the Drain is secure.

**Congratulations**, this completes the installation of the Sinkology Bath Drain.

### LIFETIME WARRANTY

All Sinkology products are fully backed with a lifetime warranty - the Sinkology Everyday Promise.



### SHOW US YOUR SINK

Join our online community of thousands of happy customers who are showcasing our products in their homes to automatically be entered into our **\$1,000 gift card giveaway**.

Visit [Sinkology.com/ShowUsYourSink](https://Sinkology.com/ShowUsYourSink) for more details.