

Is Your Kitchen Ready for a Quick-Fit® Sink?

Use this quick checklist to see if your kitchen is ready for a **DIY Quick-Fit®** farmhouse sink install.



✓ Cabinet Size Check

Measure your cabinet base width:

- 26" sinks fit 29" bases (30" preferred)
- 34" sinks require 36" bases

✓ Existing Sink Removal

- Access plumbing
- Disconnect water + drain lines

✓ Countertop Compatibility

- Existing countertop stays in place

No countertop replacement needed

✓ Cabinet Front Adjustment

- Small cut needed for apron front
- No full cabinet rebuild

✓ Gather Basic Tools

- Tape measure
- Drill / driver
- Saw
- Level
- Sealant



No countertop replacement needed

Download BILT® App for easy 3D Guided Install Instructions



Check all 5 boxes?

You're ready for Quick-Fit®:

- ✓ DIY in about an hour
- ✓ No countertop replacement
- ✓ Farmhouse style made simple



Find your fit at
Sinkology.com